

News

SSI Technologies Offers Digital Pressure Gauge in new MediaGauge™ Line

Janesville, WI, April 28, 2005 - SSI's MediaGauge™ family of Digital Pressure Gauges was launched earlier this month. The MediaGauge™ is designed for use in both harsh and benign media with the superior accuracy and represents significant cost savings over currently available digital gauges. It was designed for industrial and commercial applications where cost, size, and performance are critical.

These compact, robust gauges measure pressures from 15 Psi to 5,000 Psi and are well suited for a variety of industrial and commercial applications. Special features include: Superb accuracy of <0.25%; Robust package comprised of an all-laser-welded stainless steel design for optimal media isolation; Maximum flexibility provided by a custom ASIC which provides signal conditioning for custom calibrations and temperature compensation of -10-60° C; Compact size, excellent price/performance ratio; Nema 4X certified; 8 – 30 Volt input with 4 – 20 mA output (optional).

SSI Technologies, Inc. is an industry leader in the design and production of automotive and industrial sensors having produced over 100 million sensors since 1987. Headquartered in Janesville, Wisconsin, SSI is both QS9000 and ISO9001 certified.



The MediaGauge™ Digital Pressure Gauge with integrated signal conditioning

For more information contact:

Industrial Sales
SSI Technologies, Inc.
3200 Palmer Drive
Janesville, WI 53545
608.757.2000
608.757.2009 fax